

DU-HA[®]

DOWN UNDER-HOLDING APPARATUS

Dark Gray P/N // 10001
Light Gray P/N // 10002
Tan P/N // 10003

Installation Instructions for 99-06 + 07 Classic Chevrolet & GMC Extended Cab Trucks

Installation Instructions:

- 1 Flip up the rear seat.
- 2 Thread the nylon straps through the seat belt brackets/bottom of the seat belt under the rear seat (on top of the ledge) by sliding each strap through the back side of the brackets/seat belts so the buckle ends up on top.
- 3 Position the DU-HA under the rear seat with cut out slots facing towards the truck bed.
- 4 Thread nylon straps through the slots in the back of the DU-HA.
- 5 Secure each strap by threading the strap through the bottom of the back slot of the buckle and down through the front slot of the buckle. Tighten. The nylon straps will help secure the DU-HA in the truck.
- 6 Install the dividers by sliding them into the channel slots inside the DU-HA.
- 7 Install the foam organizer/gun racks and plastic stiffeners by putting one stiffener on each side of the foam piece and sliding them into the pre-cut slots in the dividers, making sure the high side of each piece faces towards the front (as shown).



Photo shows two models of seat belt brackets, straps should loop through.



Photo enlarged to show buckle detail



This is how the DU-HA should look installed under the back seat.

Safety Instructions:

Warning: Seat must be down and latched at all times while vehicle is moving. Make sure DU-HA is secured in vehicle according to installation instructions. Do not store explosives or hazardous materials in the DU-HA. Do not place loaded guns in the DU-HA.

For further instructions refer to truck owners manual or contact DU-HA, Inc.

Troubleshooting:

If the seat doesn't want to come all the way down, try the following:

Check to make sure that both the DU-HA and the gun rack/organizers are facing the correct direction (slots facing back/high sides forward).

On the back rest of the seat, behind each head rest and down a few inches, there are two brackets, each containing a rubber grommet. Lube these brackets using WD-40 or another form of spray lubricant. (Bottom seat must be flipped up to access these brackets.)

